The Durham OpenFOAM Tutorial

Introduction

This provides a short step by step guide to calculating the flow around an aerofoil using the *OpenFOAM* package. The aim being to introduce you the important features of the program in the shortest possible space of time. The solution presented here will require further work to be used as a basis for any serious engineering but this gets you started.

OpenFOAM is readly installable on machines running the GNU/Linux operating system. OpenFOAM is free (as in freedom) software and there is a wealth of on-line documentation and description at: <u>http://www.openfoam.org/index.php</u> This tutorial was conducted on an Ubuntu 12.04 system with OpenFOAM installed from the Ubuntu Deb Pack Installation from the above website but you can compile the system yourself if you wish!

Hint: OpenFOAM is designed for CFD specialists. Please bear in mind that it is not easy to use and you will need to edit text files and read error messages on the console carefully to get your solution to work. However once you have got over the learning curve I have had students get *very* enthusiastic about the software.

Once you have logged into your system you will need to carry out some magic to get various environment variables initialised and setup. Once this is done you can start using the program – note that you never run a program called *OpenFOAM* you run individual solvers in this case we will be running a module called *simpleFoam*.

Mesh Import

You should set-up a special directory to run your case:

\$ mkdir naca5012

Now move into the working directory:

\$ cd naca5012

then copy one of the tutorial files to your working directory, since we are doing 2D calculations on aerofoil there is a handy example entitled airfoil2D which we can use:

\$ cp -r \$FOAM_TUTORIALS/incompressible/simpleFoam/airFoil2D/* ./

obviously you need to find where the tutorials will be installed on the system to copy them to your local directory. If your environment variables are set up correctly you can get this location from the **\$FOAM TUTORIALS** shell variable.

Hint: OpenFOAM is only available on the GNU/Linux platform and so it is a good idea to get familiar with that operating system. The CIS has various guides that can help with basic operating system operations: <u>http://www.dur.ac.uk/cis/docs/category/?id=9</u>

We now need to copy the mesh to the case directory and convert it to OpenFOAM format. If you use the mesh created in the gmsh tutorial earlier it will be called naca5012_step3.msh, the command to convert it is therefore:

\$ gmshToFoam naca5012_step3.msh

This will send a bunch of text scrolling past which you can look at once the command has run to see what has happened. You can run a command to check the mesh.

\$ checkMesh

Hopefully if you follow the previous tutorial carefully this will produce no errors.

Boundary Condition Set Up

The next part can seem a little tedious – there is no graphical interface for OpenFOAM so what we need to do is adjust all the text files that describe the case from the tutorial to fit our example. If you list the files in the working directory you will see the following:

\$ ls

0 Allclean Allrun constant naca5012_step3.msh system

- 0 this directory contains information about the solution at iteration zero, i.e. the start
- Allclean this utility comes from the tutorial you can delete it if you wish
- Allrun this utility comes from the tutorial you can delete it if you wish
- **constant** this contains things that don't change during the simulation (so this is where the mesh ends up)
- naca5012_step3.msh the mesh file we just copied in
- system this directory contains parameters that control the solution procedure

So the next step is for us to edit these files "by hand" until we can run the case. This involves adjusting some files in the constant and 0 directory. We don't adjust anything in the system directory at this stage as we are happy with the settings from the tutorial at the moment – though you may want to change them later as you play with your solution.

In the gmsh tutorial we set up the mesh with the following named elements:

- back
- front
- top
- exit
- bottom
- inlet
- aerofoil
- internal

The next steps basically tell OpenFOAM via a series of text files what we would like to do with the various edges.

Altering the system directory

Here we need to make an adjustment to the mesh to inform OpenFOAM this is a 2D case this is required as OpenFOAM solvers everything in 3D.

\$ gedit constant/polyMesh/boundary

This produces a text editor which looks something like this:

Durham University

	M/des0gli-2.1.1/run/naca5012/constant/polyMesh) - gedit
File Edit View Search Tools Do	cuments Help
📄 📔 Open 🔹 💆 Save	📇 🦡 Undo 🧀 🔏 韇 💼 🔍 🛠
📄 boundary 🗱	
/*	·····*· C++ ·*····*/
======== \\ / F ield \\ / 0 peration \\ / A nd \\/ M anipulation *	OpenFOAM: The Open Source CFD Toolbox Version: 2.1.1 Web: www.OpenFOAM.org
FoamFile	*/
{	
version 2.0;	
format ascii;	
class polyBounda location "constant/	ryMesh;
object boundary;	polymesn ;
}	
// * * * * * * * * * * * *	* * * * * * * * * * * * * * * * * * * *
7 (front {	
type pa	tch:
	542;
startFace 44	018;
}	
back {	
ر type pa	tch:
nFaces 29	
startFace 73	560;
}	
exit	
{ type pa	tch;
nFaces 40	
	, 3102;
}	
bottom	
1	C - Thuidth o - 1-co cald inc
	C + Tab Width: 8 + Ln 63, Col 1 INS Figure 1: Editing the boundary File

Figure 1: Editing the boundary File

This is one of the outputs from the gmshToFoam command we ran earlier. Each of the various named elements is shown individually. We need to change the front and back types to "empty", so they should look this after editing:

front		
{		
	type	empty;
	nFaces	29542 ;
	startFace	44018;
}		
bac	:k	
{		
	type	empty;
	nFaces	29542 ;

}

startFace 73560;

Secondly we need to tell OpenFOAM that the aerofoil surface is a wall:

aerofoil	
{	
type	wall;
nFaces	410;
startFace	103282;
}	

Don't forget to save the file after you have completed the edits.

Altering the 0 directory

\$ ls 0/

```
nut nuTilda p U
```

The 0 directory contains four files which describe the system at the first iteration of the calculations:

- **p** is the pressure
- U is the velocity
- **nut** and **nuTilda** are parameters from the turbulence model being used (in this case the tutorial example uses Spallart Allmaras and so we stick with that)

The various files should be edited to add the various names of patches and apply the correct boundary or initial conditions (this is a bit tedious as you have to repeat this four times) but the p file should contain the following:

```
inlet
```

```
{
                       freestreamPressure;
    type
}
exit
{
    type
                       freestreamPressure;
}
top
{
                      freestreamPressure;
    type
}
bottom
{
                      freestreamPressure;
    type
```

```
}
aerofoil
{
                 zeroGradient;
    type
}
front
{
    type
                     empty;
}
back
{
                     empty;
    type
}
```

This should hopefully be self-explainatory – for more details on each boundary type consult the OpenFOAM documentation. The U file should contain the following information:

```
inlet
   {
                        freestream;
       type
       freestreamValue uniform (25.75 3.62 0);
   }
   exit
   {
                        freestream;
       type
       freestreamValue uniform (25.75 3.62 0);
   }
   bottom
   {
       type
                       freestream;
       freestreamValue uniform (25.75 3.62 0);
   }
   top
   {
```

```
freestream;
    type
    freestreamValue uniform (25.75 3.62 0);
}
aerofoil
{
                      fixedValue;
    type
                      uniform (0 \ 0 \ 0);
    value
}
front
{
    type
                      empty;
}
back
{
    type
                      empty;
}
```

Here values as well as types are specified, so we have a velocity set as 25.75 m/s in the x direction and 3.62 m/s in the y direction which gives an incidence of around 8 degrees and a velocity magnitude of 26 m/s. These are actually the values found in the tutorial file but they seem good enough to be going on with. The nut file should be set up as follows:

```
inlet
   {
                        freestream;
       type
       freestreamValue uniform 0.14;
   }
   exit
   {
                        freestream;
       type
       freestreamValue uniform 0.14;
   }
   top
   {
                        freestream;
       type
       freestreamValue uniform 0.14;
```

Durham University

```
}
    bottom
    {
       type
                       freestream;
       freestreamValue uniform 0.14;
    }
    aerofoil
    {
                nutUSpaldingWallFunction;
       type
                       uniform 0;
       value
    }
    front
    {
       type
                   empty;
    }
    back
    {
        type
                       empty;
    }
and the nuTilda file should have the following editing into it:
inlet
    {
                freestream;
       type
       freestreamValue uniform 0.14;
    }
    exit
    {
              freestream;
       type
       freestreamValue uniform 0.14;
    }
    top
    {
                       freestream;
        type
```

```
freestreamValue uniform 0.14;
}
bottom
{
                     freestream;
    type
    freestreamValue uniform 0.14;
}
aerofoil
{
    type
                     fixedValue;
    value
                     uniform 0;
}
front
{
                     empty;
    type
}
back
{
                     empty;
    type
}
```

Running the Solver

The next step is to simply run the solver, change to the working directory and run the solver:

\$ simpleFoam

This then sends lots of text wizzing past the terminal as OpenFOAM explains what it is doing as it goes along. On my laptop the solution took around one minute to solve and I end up with something like this in the terminal window:

```
😣 🗐 🗊 🖉 Terminal
File Edit View Search Terminal Help
05, No Iterations 1
time step continuity errors : sum local = 2.21888e-05, global = 2.03074e-15, cum
ulative = 1.16396e-12
smoothSolver: Solving for nuTilda, Initial residual = 1.06611e-05, Final residu
al = 6.46822e-07, No Iterations 4
ExecutionTime = 62.48 s ClockTime = 64 s
Time = 500
smoothSolver: Solving for Ux, Initial residual = 0.000138676, Final residual =
1.03105e-05, No Iterations 4
smoothSolver: Solving for Uy, Initial residual = 6.24987e-05, Final residual =
4.84704e-06, No Iterations 4
GAMG: Solving for p, Initial residual = 0.00053415, Final residual = 3.99477e-0
5, No Iterations 2
time step continuity errors : sum local = 1.71187e-05, global = 3.61173e-15, cum
ulative = 1.16757e-12
smoothSolver: Solving for nuTilda, Initial residual = 1.05542e-05, Final residu
al = 6.40361e-07, No Iterations 4
ExecutionTime = 62.8 s ClockTime = 64 s
End
[naca5012]$
```

Figure 2: A Successful Solution

If you don't get a successful solution you need to do some troubleshooting, this basically involves reading the error messages carefully and working out what to do. This isn't difficult but requires patience and precision.

Hint: SimpleFoam is so called because it uses the Semi-Implicit Method for Pressure-Linked Equations in the solution. To get other solution methods you need to run other modules such as icoFoam which is a transient solver for incompressible, laminar flow of Newtonian fluids

Using the default values from the tutorial means we haven't had to think very much about solver parameters or even make a choice of turbulence models and these are things you should certainly consider if you were to want to use these results.

Post Processing

So far all we have is a bunch of text scrolling up the screen, to understand and interpret the results we need to post process them. This is done using an open source visualisation package called Paraview. You can use this in a number of ways the easiest is just to launch it from the command line from the working directory:

\$ paraFoam

This gives you a window that looks like this:

OpenFOAM Tutorial

Durham University

<mark>8 – –</mark> ParaView 3.12.064 File <u>E</u> dit <u>V</u> iew <u>S</u> ources Fi	전 전경감				
		🗱 🛣 📕		🕅 🖏 Time: 🛛	0
	Representatio		*** 1** 1*	- # # # # @	GG
	002200				
	Pipeline Browser	ex Pr			
Duiltin:					
Properties Display Inform	Object Inspector nation Beset Skip Zero Time Patch Names				
Include Sets Interpolate volFields Use VTKPolyhedron	 Include Zones Extrapolate Patches 				
Update GUI					
Mesh Parts Mesh Parts front - patch back - patch wit - patch bottom - patch inlet - patch top - patch aerofoil - patch			Y		
🗑 Volume Fields				X	
nuTilda nut ¥ p ¥ U			« I		

Figure 3: ParaView Initial Window

Hit the highlighted apply button to load the data. The switch the Object Inspector (Bottom Left) to the Display Tab and then change the Color to "p" using the drop down as shown:

Durham University

😸 🖨 🗊 ParaView 3.12.0 64-bit	
File Edit View Sources Filters Tools Macros Help	
😰 🤌 🐯 🖉 🤌 🔍 💞 🦹 🙀 🏧 🎇 👯 🔣 🕷 🐁 🔤 📣 🔊 🔊 🌆 Time: 💽 🖉 📮	
📱 🎴 🛱 💿 Solid Color 🔹 🔹 Surface 🔹 🔣 😳 🗳 🕌 🛱 🛱 🛱 🎯 🚱 🔾	
[] [] [] [] [] [] [] [] []	
Pipeline Browser] ×
i builtin: ▶ maca5012.0penFOAM	
Object Inspector	
- View	
X Visible Zoom To Data	
X Selectable	
Color	
Interpolate Scalars	
Map Scalars	
Apply Texture None	
O Set Solid Coor cellNormals	
Sine	
Slice Direction	
- Annotation	
Show cube axes Edit	
-Style	
Representation Surface 👻	
Interpolation Gouraud	
Opacity 1.00 ÷	
Subdivision 1	
Volume mapper Projected tetra	
Edge Style	

Figure 4: Changing the Contours to Pressure

By default this reads in time or iteration 0, so use the time controls at the top right to select the last time for the solution:

OpenFOAM Tutorial

Durham University

🛞 🖨 🐵 ParaView 3.12.0 64-bit	
<u>File Edit View Sources Filters Tools Macros H</u> elp	
	š 🕅 📲 🕨 🙌 🗱 Time: 500 10 🚍
Surface 🔹) 🔀 😳 📫 🕌 🏥 🙀 🕶 🕶 😁 輝 🎯 🚱 🕃
6 6 😒 🛳 🧟 🖤 🕸 🕼 🕼	
Pipeline Browser	
 builtin: naca5012.0penFOAM 	
Object Inspector	
Color Interpolate Scalars Map Scalars Apply Texture None Color by Edit Color Map Rescale to Data Range	
Slice Slice Direction Slice Annotation Show cube axes Edit	
Style Representation Surface Interpolation Gouraud Point size 2.00 Line width 1.00 Opacity 1.00 Subdivision 1 Volume mapper Projected tetra	Z X

Figure 5: Selecting the Last Iteration and Changing the Scales

You will then need to use the controls highlight to scale the contours to give you a useful output. Note that Paraview is displaying the 3D shape use a "Filter" to cut through the shape and give you a true 2D plane to look at.

Filters \rightarrow Common \rightarrow Slice. Then select Z normal and apply.

Filters \rightarrow Common \rightarrow Contour. Then click on New Range to generate a range of pressure to contour and then hit apply. Your slice will then disappear to find again click on the eye icon in the tree menu at the top.

This should give you something like the following picture:

OpenFOAM Tutorial

Durham University

e Dara (view 3.12.0 64-bi		s <u>H</u> elp							
		A 2 G		*			🔂 Tim	ie: 500	10	•
	A SC	G. 1	a tink tink sole over the							
📕 🔓 🛱	♦ p		▼ Surface	- 2	I 🗔 📫	1 👪 👫 🕯	1 📫 1	3	5 🚱 🕻	
	M M	0 🗟 🤌	6							
	Pipe			7 X 👔						
builtin: naca5012.										
Contour1										
	Obj isplay Informati									
) <u>R</u> eset 🛛 🗱 D	elete ?							
- 🗄 - Contour			11/22							
Contour By		◇ p								
Compute M										
Compute Sc										
- Isosurfaces -		100								
Value Range: [- 1322.92	-1322.92, 364.106]		Delete						the state of the s	
-1252.62725								EN.		
-1182.3345 -1112.04175			Delete All							
-1041.749 -971.45625			New Value							
-901.1635 -830.87075			New Range	1						
-760.578			Scientific							
-690.28525 -619.9925										
-549.69975										
-479.404526										
-409.11425 -338.8215										
-268.52875										
oint Merge Metl		Uniform B	anning							
- 🗄 - Uniform Binr		50	50			1. Sec. 19				
Divisions	50	1 20	1 50	-						
Number of points per bucket	8									
and the second se				_						

Figure 6: Contours of Pressure Around the Aerofoil

Obviously you need to do some work to make sure the solution is any way reasonable – but that at least gets you started....

Grant Ingram Wednesday 14 November 2012